

1" Button Maker

SHELL DIE:

Place the shell in the SHELL DIE with the sharp edge facing down.
Place the artwork (facing up) on top of the shell.
Place the clear mylar cover on top of the artwork.

BACK DIE:

Place the back ring in the BACK DIE with the sharp edge facing up.

SHELL DIE:

Rotate the SHELL DIE until it lines up under the press.
Pull the press handle down all the way. Release.

BACK DIE:

Rotate the BACK DIE around until it lines up under the press.
Pull the press handle down all the way. Release.

Remove your new button!